



KETTLER P-04 Parasol Base




Parts List


<p>(A) Base (B) (C)</p> <p>x1</p>	<p>(F) Tube Stem</p> <p>x1</p>	<p>(G) Locking Knob</p> <p>x1</p>	<p>(H) Adapter Collars</p> <p>These can be found in the tube stem (B)</p> <p>x3</p>
<p>(E) Washer</p> <p>x1</p>	<p>(D) Flat Washer</p> <p>x1</p>	<p style="text-align: center;">!</p> <p style="text-align: center;">Do not discard any of the packaging until you have checked that you have all the parts and the pack of fixings.</p>	



Helpful advice before you begin:

1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
3. Assemble this product on a soft surface.
4. Keep fittings out of children's reach.
5. Do not use any other tools other than those recommended to build this product.
6. Please do not use substitute parts. Use only additional or replacement parts supplied by Kettler.
7. In the unlikely event that this product has missing or damaged parts, please visit our website www.kettler.co.uk





Warranty For Home Use

This item is covered by a 12 MONTH KETTLE WARRANTY.
The warranty applies to domestic use only.
The warranty does not cover accidental damage or mis-use.
To validate your warranty, register at
www.kettler.co.uk and quote the product code P-04 (where relevant)

KETTLE



www.kettler.co.uk